





Flow Indicator

Application

Indicates direction of flow of compatible liquids in pipelines at working pressures up to 500 psig [34 Bar]. The indicator must be installed in pipeline tees.


General Information & Features*

The head, centershaft, support tube, bearings and vane in these indicators are made of 300 Series stainless steel. Magnets are nickel-plated Alnico, and the threaded mounting adapters are forged steel.

Replaceable Parts

Model #	Description	
5013S00048	4" [100] dial	
0040-00413	Mounting screws for 4" dial	
0040-00666	Stainless steel mounting bolts %"-24 x ¾"	
0015-00462	Teflon filled stainless steel gasket	
0015-00401	Teflon gasket	
0093-00002	4" dial bracket	
0040-00022	Bracket screws	
0039-00002	Aluminum bezel ring for 4" dial	
0022-05211	2" NPT mounting adapter	
0022-05280	1 ¼" NPT mounting adapter	

NOTE: Torque mounting bolts to 140-150 in-lb. [16,4 Nm]





Model Numbers

Model #	Description
6286-00325	Flow indicator with 4" dial, 2" NPT adapter and 3 ½" "A" dimension
6286-00475	Flow indicator with 4" dial, 2" NPT adapter and 4 ½" "A" dimension

Tee Size NPT	"A" Dimension	
2" x 2" x 2"	3 1/4"	
2 ½" x 2 ½" x 2"	[82,5]	
3" x 3" x 2"	4 ¾" [95]	
2 ½" x 2 ½" x 2 ½" with 2 ½" x 2" bushing		
3" x 3" x 3" with 3" x 2" bushing		

The distance from the top of the mounting adapter to the end of the vane is the "A" dimension. This dimension is dependent on the tee size, as shown above.

Flow indicators with special "A" dimensions may be available — specify your requirements.

Note: For bolted gauges installation instructions see MS-501/502. For threaded gauge installation instructions see MS-516.



02/26/2018



^{*} Materials and specifications are subject to change without notice.
Pressure ratings subject to change due to temperature and other environmental considerations.